



### **Hingex Finger Protection Fitting Instructions**

1. Measure and cut (with hacksaw or mitre snips) a piece of Hingex to fit above top hinge to the top of the door.
2. Measure and cut a piece of Hingex to fit below bottom hinge to the bottom of the door.
3. Measure and cut 2 pieces of Hingex to fit in between hinges.
4. Ensure that the surfaces that are to be adhered to are free from dust or grease.
5. Remove backing tape from each piece in turn and stick through the hinge gap onto the door frame.
6. Repeat for all cut pieces.
7. Close door and allow tape adhesive to cure off over night.