



MXS 15-56

Fitting Instructions

- 1.** Remove rubber seals from aluminium sill section. Measure width between inside faces of the doorframe rebate and cut aluminium section to this size
- 2.** Notch both ends of the sill to allow it to fit into the doorframe rebate.
- 3.** Cut rubber seals 10mm longer than the aluminium and reinsert into grooves in sill.
- 4.** This sill requires an under door clearance of 13mm. If necessary, remove door and trim to allow for this, ensuring bottom of door is smooth to avoid damage to rubber seal.
- 5.** Position the assembled sill between the doorframe and mark fixing points through countersunk holes. Remove sill, drill fixing holes and insert plugs.
- 6.** Apply sealing compound (Exitex Elast-O-Sealant) to underside at front and back of sill and screw sill into place.