



SEALED IN QUALITY

MXS Lowline

Fitting Instructions

- 1.** Remove rubber seal from aluminium sillsection. Check width between outside faces of the doorframe rebate and cut aluminium section to this size.
- 2.** Cut the rubber seal to width between the inside faces of the doorframe rebate to allow seal to extend into kwitfit lugs and re-insert into groove in sill. Attach kwitfit lugs to each end of sill.
- 3.** This sill requires an under door clearance of 20mm. If necessary, remove door and trim, ensuring bottom of door is smooth to avoid damage to rubber seal.
- 4.** Position the sill between the door frame and mark fixing points through countersunk holes. Remove sill, drill fixing holes and insert plugs.
- 5.** Apply sealing compound (Exitex Elast-O-Sealant) to underside groove at