



MXS

Fitting Instructions

- 1.** Remove rubber seal from aluminium sill section. Check width between outside faces of the doorframe rebate and cut aluminium section to this size, cutting at the opposite end to the replacement seal hole.
- 2.** Cut the rubber seal longer than aluminium section to allow seal to extend into the kwitfit lugs and re-insert into the groove in sill. Attach kwitfit lugs to each end of the sill.
- 3.** This sill requires an under door clearance of 25mm. If necessary, remove door and trim to allow for this, ensuring bottom of door is smooth to avoid damage to rubber seal.
- 4.** Position the assembled sill between the doorframe and mark fixing points through countersunk holes. Remove sill, drill fixing holes and insert plugs.
- 5.** Apply sealing compound (Exitex Elast-O-Sealant) to underside groove at back of sill and around kwitfit lugs. Ensure rubber seal is in place and screw sill into place.